WUKE

REMOTE CONTROL

WKR3

User Manual

FAIRMATE

comfortable technology

www.fairmate.it

ANDROID

Highlights

- All in one, Air mouse, Android control, TV control
- Wireless RF(2.4G)
- IR Learning
- Voice Control
- Vibrator For game
- QWERTY Keyboard
- Touch Wheel for Browsing

How to use Motion remote control

SR100 is a new Multi-Function of Intelligent Remote Control Device, support the Air Mouse with 6 axis, 16 k MIC sampling, having many strong functions such as standard Qwerty keyboard, touch motion, vibration, infrared remote control and infrared learning and so on.

Remote Controller

1. Signal Indicator Instructions

D1：To operate any buttons of remote control in side A, D1 signal indicator will flicker.

D2：Press SET button for 3 seconds to use the remote control learning function, and gnal indicator will be in a slow flicker state.

2. Remote Matching

1) When using SR100 RCU，please make sure the matching like below.
2) Hold the OK button + (recall button）simultaneously in side A，the D1 indicator will flicker quickly.
3) Insert the USB connector of SR100 into the usb interface on the stick, and then will match successfully in about 5seconds.
4) If it failed to match, please pull out the USB connector, and insert it into the stick again，first to ensure that the stick have identified the USB device, and then repeat the step 1 and step 2 to match.

3. Sensitivity adjust

Hold the OK button and VOL+/- button to change the sensitivity control.

1) Hold the OK button and press VOL+ button to adjust the high sensitivity.
2) Hold the OK button and press VOL- button to adjust the low sensitivity.
3) when adjust the sensitivity, the D1 indicator will flicker quickly，the remote controller have seven mode support.

note: if adjust the sensitivity the most or least，the D1 indicator not flicker.

4. Cursor control

1) Extract the battery first，hold the OK button and put the battery again，put the remote controller on the horizontal position.
2) When the D1 indicator will flicker quickly，the cursor control is successful.

5. 2.4G and Infrared mode switch

Hold the LOCK button of remote control in side B more than 3seconds，to switch between2.4 G and infrared mode, when using switching function, there will be a vibration tip.

6. MIC Function

Hold the voice button to open speech function

A1 for voice input hole

A2 for horn output hole with speaker

7. Touch Function

Sliding the remote control direction buttons from right to left counterclockwise, the mouse wheel function upward; while sliding from left to right clockwise, the mouse wheel function downward.

When using touch function，There will be a sound tip.

8. Qwerty Keyboard

When using Qwerty keyboard, you can hold the motion remote control like below,In this time，the cursor on the TV will moving according to you moving.

Press to switch the capital.

Press ALT key to switch the special character.

Press ALT key to switch user the UP/DOWN/LIGHT/RIGHT key to moving direction.

Note: if the indicator lights on the LOCK button always light，and when you press any key on the side B，the indicator lights will be blink，the motion remote control work on the the 2.4G mode.

if the indicator lights on the LOCK button always no light，and when you press any key on the side B，the indicator lights will be blink，the motion remote control work on the the IR mode.

9. Learning Function

Hold the SET button for 3 seconds，and D2 signal indicator will be in a slow flicker state，At this time, entering into the learning function of remote control button codes. To learn remote control button codes when the infrared sending IR Receiver of the remote control to be learned is horizontally aligned to that of SR100.

1) When pressing the button of remote control to be learned, if SR100 receives the button coding, the D2 indicator light will show quick flicker; If not receiving successfully, need to press this button again.
2) When SR100 has received the key coding, press the corresponding learning button of SR100, the D2 will show slow flicker to indicate successful learning.
3) To learn to use the other keys by repeating the above steps 1&2
4) When finished studying the key codes, press SET key to exit learning mode, and the D2 light will go out.

10. Automatic Shutdown Function

1) In search state, if not connected successfully within 15 seconds, automatically entering into the sleep mode.
2) In connection state, if no actions within 1 minutes, automatically entering into the sleep mode.
3) In any state, press any button of SR100, automatically awaken the remote control
4) In infrared mode, if no actions within 10 seconds, automatically entering into the sleep state.

11. Battery Instructions

SR100's normal work needs to use 3 disposable or lithium batteries of size 5.And the D4 interface is for lithium battery charging.

When charging the battery, the D2 indicator will flicker. When the battery is low, the D2 indicator will flicker lly aligned to that of SR100.

Specification

Transmission Mode	IR/Wireless RF
Carrier Frequency	38K/2.4GHz
Agreement	HID(Nordic IC)
IR Learning Type	YES(optional)
Number of Keys	Front 53 units；Back 42 units（qwerty keyboard）
Full keyboard or Not	YES
3D GAME	Support （motor shake）(optional)
LED Display	3 units
Touch Wheel for Browsing	Support
MIC Voice Control	Support(optional)
Low Power Indicator	YES
Type of Battery	3*AAA Battery(Ni-MH battery charging optional)
Mini USB	Ni-MH battery charging
Dongle	External USB Dongle
Operating Voltage	3.5V-4.5V
Power Consumption	<25mAh
Operation Temperature	-＋5℃~＋50℃
Key Life	300，000 times
Effective Control Distance	10m
Size (WxDxH) in mm	55x170x20
Weight	30g

DICHIARAZIONE CE DI CONFORMITA'

CE CONFORMITY DECLARATION

La società / The Company: **RITAR** S.p.A. arrotondata

indirizzo / address: **Via Maragliano 102/d – 50144 Firenze (ITALY)**
www.ritar.com – info@ritar.com

DICHIARA, sotto la propria responsabilità, che il prodotto
DECLARES, under its own responsibility, that the product

Marchio / Trade mark: **FAIRMATE**

nome del prodotto: WUKE, WUKE remote

soddisfa i requisiti essenziali delle Direttive EMC, LVD, FCC, RoHS

EMC test standards:

EN55022:1998+A1:2000+A2:2003
EN50130-4: 2011
EN55024:2007
EN61000-3-2: 2000+A1:2009+A2:2009;
EN61000-3-3: 2008

LVD test standards :

EN60950-1: 2006+A12: 2011

FCC PART 15 : 2010 SUBPART B

RoHS test standards :

2011/65/EU;
2006/95/EC;
IEC 62321:2008.

Data 01/01/2013
Date

Firma :
Signature

RITAR S.p.A.
UFFICIO LEGALE

Amministratore Delegato